

# **THERMAL-GRIP® INSULATION PIN**

PRODUCT INFORMATION





Concrete Applications

Steel Applications



#### **PRODUCT DESCRIPTION**

The Thermal-Grip<sup>®</sup> Insulation Pin is a large 2.25" diameter washer head fastener with pins available to attach insulation to concrete/CMU or 14-18 gauge steel studs. Anchor pins are available in lengths from 1" to 6". Use with Thermal-Grip IP Insulation Fastening Tools for rapid attachment.

#### **PRODUCT SPECIFICATIONS**

Basis of Design: Thermal-Grip® Insulation Fastening Tool as manufactured by TRUFAST® Walls.


**Application:** The IP50D tool is a concrete pinner tool designed to attach insulation to a concrete wall. Gas-actuated insulation fasteners. No screws or adhesives required.


- a. Permanently attaches insulation with a flush finish.
- b. For use attaching all types of rigid insulation including XPS, EPS, polyisocyanurate and mineral wool.

Description: 2-1/4" (57mm) diameter, solid plastic, to reduce thermal bridging

Lengths: Anchor lengths available for insulation 1"- 6" thick

### **PRODUCT SELECTION**





MATERIAL SPECIFICATIONS

R1.18 R1.18 Anchor Length 0.5 Ø.60 Ø.60





# **THERMAL-GRIP® INSULATION PIN**

PRODUCT INFORMATION

### **APPROPRIATE ACCESSORIES**

Thermal-Grip<sup>®</sup> IP Insulation Fastening Tools to rapidly attach insulation to concrete, masonry, and tilt up/ precast walls



Low-Mid Range PSI Use with Insulation Pins 1"- 4"




Mid-High Range PSI Use with Insulation Pins 1.5"- 6"

Pinner Tool Fuel Cell

## **PRODUCT FEATURES**

- Anchor lengths available from 1" to 6" to match insulation thickness
- Large 2.25" diameter washer head secures insulation
- · Pins (TGIP) available for attaching insulation to concrete/CMU
- Pins (TGIP-ST) available for attaching insulation to 14-18 gauge steel studs
- Can be used to attach EPS, XPS, ISO, and mineral wool insulation



#### **INSTALLATION GUIDELINES**

- · Ensure fuel cell and battery are properly inserted into the tool.
- Place fastener on end of barrel.
- · Push the fastener into the insulation to release safety.
- Once the safety is released, pull trigger to install the fastener.



#### Bulletin No. TFW-23112

#### DISCLAIMER

The information provided here is subject to change without notice. The performance specifications published in this TRUFAST<sup>®</sup> Walls product literature are based on controlled laboratory tests and are intended as a guideline only. They are not guaranteed in any way by the ALTENLOH, BRINCK & CO. US, INC., since building

design, engineering, and construction, including workmanship and materials, are beyond the control of the manufacturer. The manufacturer recommends that pull-out tests be conducted to verify the substrate provides adequate pull-out values.

